

## Radio-frequency communication module (to use with controlling system) 80x56 מ"מ

**XJ150**



- Radio communication system for controlling and supervising units
- Cover all application fields, from single benches to cold rooms and compressor racks
- The information coming from the controller are transmitted to an XJ100 module and directly sent to the XJ150 connected to the controlling and supervising unit
  - Possibility to connect many instruments to the same XJ100
  - XJ100 automatic "bridge" function to increase signal throughput between modules
    - Easy to use
    - Less installation time and costs
    - High flexibility
    - 0,25VA max power absorption
- Operating frequency: 433,5068MHz
  - Range: 80m (no obstacles)
  - Wall or panel mounting
  - Power supply:
    - XJ100 (5Vdc directly from the controller);
    - XJ150 (5Vdc from PWS150J module)